

Universal joints ridge unit on Rustica sheet profile



Item	Colour	Dimensions mm	Matching sheets
GLRU15	black	50x115x1520	RU021TNR - RU021ANF - RU021ANV - RU021ANS

Material: Rubber

Features: Useful accessory to ensure greater water seal and air tightness.

Installation: Installing the ridge joints is a very simple operation, which allows the ridge to be sealed in correspondence with the lateral waves.

- The joints must be applied between the sheet and the lower part of the ridge; it is advisable to position the joint as close as possible to the external edge to allow maximum compression and therefore the best waterproofing of the roofing (fig. 1).
- Joint fitting: clean the surface of the sheet well with a non-aggressive product, turn the adhesive side of the joint towards the sheet, and after removing the protection, fix it with light pressure (fig. 2).
- Position the ridge over the joint and drill it with a 10 mm drill bit. To optimize the water seal, the hole must be made in correspondence with the upper part of the wave of the sheet and in the middle of the joint (fig. 3).
- Fix the ridge, joint, and Rustica sheet to the load-bearing structure with a flat cap with 150 mm screws (fig. 4).

