


Universal joints ridge unit on Latina sheet profile



Item	Colour	Dimensions mm	Matching sheets
GL1470	black	50x70x1490	LLF019TC - LLF019TN


Material: Rubber

Features: Useful accessory to ensure greater water seal and air tightness.

Installation: Installing the ridge joints is a very simple operation, which allows the ridge to be sealed in correspondence with the lateral waves.

Before drilling the ridge and the sheets, make sure, by presenting them, that the various parts of the roof are perfectly matched.

- The joints must be applied between the sheet and the lower part of the ridge; it is advisable to position the joint as close as possible to the external edge to allow maximum compression and therefore the best watertight (fig. 1).
- Joint fitting: clean the surface of the sheet well with a non-aggressive product, turn the adhesive side of the joint towards the sheet and, after removing the protection, fix it with light pressure (fig. 2).
- Place the ridge over the joint and drill it with a 10 mm bit.



ATTENTION: to optimize the watertight, the hole must be made in correspondence with the upper part of the wave of the sheet and in the middle of the joint (fig. 3).

• Fix the ridge, joints and Roofing sheet Latina to the load-bearing structure with a flat cap and 130/150 mm screws. (fig. 4).

