

## Universal joints ridge unit on Onda Romana and Romana Egeo reinforced sheet profile



Item	Colour	Dimensions mm	Matching sheets
<b>GLRE15</b>	black	50x70x1500	ONLF021VO - ONLF031VO - ONLF042VO ONLF021GS - ONLF031GS - ONLF042GS ONLF021TN - ONLF031TN - ONLF042TN RE031GOP - RE042GOP - RE052GOP - RE062GOP RE031ROP - RE042ROP - RE052ROP - RE062ROP RE031MOP - RE042MOP - RE052MOP - RE062MOP RE031BOP - RE042BOP - RE052BOP - RE062BOP

**Material:** Rubber

**Features:** Useful accessory to ensure greater water and air tightness.

**Installation:** Installing the ridge joints is a very simple operation, which allows the ridge to be sealed in correspondence with the lateral waves.

- The joints must be applied between the sheet and the lower part of the ridge; it is advisable to position the joint as close as possible to the external edge to allow maximum compression and therefore the best waterproofing of the roof (fig. 1).
- Fitting the joint: clean the surface of the sheet well with a non-aggressive product, turn the adhesive side of the joint towards the sheet, and after removing the protection, fix it with light pressure (fig. 2).
- Position the ridge over the joint and drill it with a 10 mm drill bit. To optimize the water seal, the hole must be made in correspondence with the upper part of the wave of the sheet and in the middle of the joint (fig. 3).
- Fix the ridge, joint and sheet to the load-bearing structure with a flat cap with 150 mm screws (fig. 4).

